



pedaltrain[®]
www.pedaltrain.com

powertrain1250

mounting template

Instructions: Place this template inside desired channel on the bottom side of your pedaltrain. Drill (4) holes through the rails at corner points indicated on template. Holes should be a minimum of 1/8 or 3mm, or a maximum of 3/16 or 5mm. Remove rubber feet from bottom of the powertrain1250 and install screws only through top side of the pedaltrain frame to secure.