

How to Reboot Pedaltrain SST Tuner

Follow these steps to reinitialize the memory of your Pedaltrain SST:

1. Disconnect power from the SST
2. Press and hold the calibration button
3. Continue holding the calibration button and reconnect power
4. Display will flash "133" and initiate reinitialization sequence
5. Once reboot sequence begins release the calibration button
6. The reinitialization will be complete when the word "PEDALTRAIN" scrolls across the display

